# PCI-DAC6702 and PCI-DAC6703

Analog Output and Digital I/O

# **User's Guide**

December 2020. Rev 4 © Measurement Computing Corporation



#### **Trademark and Copyright Information**

Measurement Computing Corporation, InstaCal, Universal Library, and the Measurement Computing logo are either trademarks or registered trademarks of Measurement Computing Corporation. Refer to the Copyrights & Trademarks section on <u>mccdaq.com/legal</u> for more information about Measurement Computing trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies.

© 2020 Measurement Computing Corporation. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form by any means, electronic, mechanical, by photocopying, recording, or otherwise without the prior written permission of Measurement Computing Corporation.

#### Notice

Measurement Computing Corporation does not authorize any Measurement Computing Corporation product for use in life support systems and/or devices without prior written consent from Measurement Computing Corporation. Life support devices/systems are devices or systems that, a) are intended for surgical implantation into the body, or b) support or sustain life and whose failure to perform can be reasonably expected to result in injury. Measurement Computing Corporation products are not designed with the components required, and are not subject to the testing required to ensure a level of reliability suitable for the treatment and diagnosis of people.

# Table of Contents

Preface
About this User's Guide4
What you will learn from this user's guide 4
Conventions in this user's guide
Where to find more information
Register-level programming
Chapter 1 Introducing the PCI-DAC6702 and PCI-DAC67035
Overview
Functional block diagram
Chapter 2 Installing the PCI-DAC6702 and PCI-DAC67037
Unpacking7
Installing the software7
Installing the hardware7
Signal connections       8         Connector pinout       9         Cabling       11         Field wiring and signal termination accessories       12
Chapter 3 Calibrating the PCI-DAC6702 and PCI-DAC670313
Calibration theory
Chapter 4 Specifications14
Analog output 14
Analog output calibration 15
Digital input / output 15
Power consumption 15
Environmental 15
Mechanical 15
Main connector and pin out
Declaration of Conformity

# About this User's Guide

## What you will learn from this user's guide

This user's guide explains how to install, configure, and use the PCI-DAC6702 and PCI-DAC6703 boards so that you get the most out of the voltage and current analog outputs and digital I/O features. This user's guide also refers you to related documents available on our web site, and to technical support resources.

# Conventions in this user's guide

#### For more information

Text presented in a box signifies additional information and helpful hints related to the subject matter you are reading.

**Caution!** Shaded caution statements present information to help you avoid injuring yourself and others, damaging your hardware, or losing your data.

**bold** text **Bold** text is used for the names of objects on the screen, such as buttons, text boxes, and check boxes.

*italic* text Italic text is used for the names of manuals and help topic titles, and to emphasize a word or phrase.

## Where to find more information

Additional information about PCI-2511 hardware is available on our website at <u>www.mccdaq.com</u>. You can also contact Measurement Computing Corporation with specific questions.

- Knowledgebase: <u>kb.mccdaq.com</u>
- Tech support form: <u>www.mccdaq.com/support/support\_form.aspx</u>
- Email: <u>techsupport@mccdaq.com</u>
- Phone: 508-946-5100 and follow the instructions for reaching Tech Support

For international customers, contact your local distributor. Refer to the International Distributors section on our web site at <u>www.mccdaq.com/International</u>.

### **Register-level programming**

You should use the Universal Library to control your board. Only experienced programmers should try registerlevel programming.

If you need to program at the register level in your application, refer to the *Register Map for the PCI-DAC6700* Series. This document is available on our website at <u>www.mccdaq.com/registermaps/RegMapPCI-DAC670x.pdf</u>.

# Introducing the PCI-DAC6702 and PCI-DAC6703

#### **Overview**

PCI-DAC6702 and PCI-DAC6703 boards are high-resolution analog output and digital I/O boards designed for PCI bus-compatible computers. You can use PCI-DAC6702 and PCI-DAC6703 boards for various digital I/O and DC setpoint applications.

The PCI-DAC6702 provides 8 analog outputs, and the PCI-DAC6703 provides 16 analog outputs. The voltage output range for each board is  $\pm 10.1$ V volts.

Each board has eight TTL-compatible digital I/O channels that are configured as one eight-bit port. You can configure each channel individually as either input or output. Digital channels are configured as inputs by default. Digital bits are pulled up to +5V with  $47 \text{ k}\Omega$  resistors. Positions are available for pull-down resistors.

PCI-DAC6702 and PCI-DAC6703 boards have a 16-bit digital to analog converter (DAC) that may be periodically updated with new channel data. DAC channel data is stored in nonvolatile RAM (nvRAM). Each channel has a main circuit that maintains the channel value between DAC updates.

PCI-DAC6702 and PCI-DAC6703 boards are equipped with an onboard temperature sensor that measures the air temperature flowing over the board.

Each board features plug-and-play installation and on-board digital calibration. All I/O signals are transmitted through a 100-pin connector.

# Functional block diagram

PCI-DAC6702 and PCI-DAC6703 board functions are illustrated in the block diagram shown here.




Figure 1. PCI-DAC6702 and PCI-DAC6703 functional block diagram

# Installing the PCI-DAC6702 and PCI-DAC6703

# Unpacking

As with any electronic device, you should take care while handling to avoid damage from static electricity. Before removing the device from its packaging, ground yourself using a wrist strap or by simply touching the computer chassis or other grounded object to eliminate any stored static charge.

Contact us immediately if any components are missing or damaged.

#### Installing the software

Refer to the *MCC DAQ Quick Start* and the PCI-DAC6702 and PCI-DAC6703 product page on our website for information about the software that supports the device.

#### Install the software before you install your device

The driver needed to run the PCI-2511 is installed with the software. Therefore, you need to install the software package you plan to use before you install the hardware.

#### Installing the hardware

PCI-DAC6702 and PCI-DAC6703 boards are completely plug-and-play, with no switches or jumpers to set. Configuration is controlled by your system's BIOS.

#### Install the MCC DAQ software before you install your board

The driver needed to run your board is installed with the MCC DAQ software. Therefore, you need to install the MCC DAQ software before you install your board. Refer to the *Quick Start Guide* for instructions on installing the software.

- 1. Turn your computer off, open it up, and insert your board into an available PCI slot.
- 2. Close your computer and turn it on.

When connected for the first time, a **Found New Hardware** dialog opens when the operating system detects the device. When the dialog closes, the installation is complete. If you have not installed the MCC DAQ software, cancel the dialog and install it now.

3. To test your installation and configure your board, run the InstaCal utility installed in the previous section. Refer to the *Quick Start Guide* that came with your board for information on how to initially set up and load InstaCal.

If your board has been powered-off for more than 10 minutes, allow your computer to warm up for at least 15 minutes before acquiring data. This warm-up period is required in order for the board to achieve its rated accuracy. The high-speed components used on the board generate heat, and it takes this amount of time for a board to reach steady state if it has been powered off for a significant amount of time.

# **Signal connections**

The table below lists the board connectors, applicable cables, and compatible accessory products for the PCI-DAC6702 and PCI-DAC6703.

Connector type	Shielded, SCSI 100-pin D-type
Compatible cables	C100HD50-x unshielded round cable. $x = 3$ or 6 feet. (Figure 2)
	C100MMS-x shielded round cable. $x = 1, 2, or 3$ meters. (Figure 3)
Compatible accessory products with the	BNC-16SE
C100HD50-x cable	BNC-16DI
	CIO-MINI50
	CIO-TERM100
	SCB-50
Compatible accessory products with the	SCB-100
C100MMS-x cable	BNC-DI-FE

Board connectors,	cables.	and accessor	v equipment
bourd connoctoro,	oubio0,	una 40000001	y oquipinone

#### More information on signal connections

For general information regarding signal connection and configuration, refer to the *Guide to Signal Connections* (available on our website at <u>www.mccdaq.com/support/DAQ-Signal-Connections.aspx</u>).

## **Connector pinout**

The main I/O connector pinouts for each board are shown in the following tables. Note that the DIO[7:0] signals are provided in two locations in order to provide flexibility for applications which use the C100HD50-x ribbon cable.


Signal name	Pin		Pin	Signal name
GND	100	••	50	GND
n/c	99	••	49	n/c
n/c	98		48	DIO7
n/c	97		47	DIO6
GND	96		46	DIO5
n/c	95		45	DIO4
n/c	94	•••	44	n/c
	94	•••	44	DIO3
n/c		••		
DIO7	92	••	42	DIO2
DIO6	91	••	41	DIO1
DIO5	90	••	40	DIO0
DIO4	89	••	39	PC 5V
DIO3	88	••	38	n/c
DIO2	87	••	37	n/c
DIO1	86	••	36	n/c
DIO0	85	••	35	n/c
AGND	84	••	34	AGND15
n/c	83	••	33	VCH15
AGND	82	••	32	AGND14
n/c	81		31	VCH14
AGND	80		30	AGND13
n/c	79		29	VCH13
AGND	78		28	AGND12
n/c	77	•••	27	VCH12
AGND	76	••		AGND11
		•••	26	
n/c	75	••	25	VCH11
AGND	74	••	24	AGND10
n/c	73	••	23	VCH10
AGND	72	••	22	AGND9
n/c	71	••	21	VCH9
AGND	70	••	20	AGND8
n/c	69	••	19	VCH8
AGND	68	••	18	AGND
AGND	67	••	17	AGND7
n/c	66	••	16	VCH7
AGND	65	••	15	AGND6
n/c	64	••	14	VCH6
AGND	63	••	13	AGND5
n/c	62	••	12	VCH5
AGND	61	••	11	AGND4
n/c	60		10	VCH4
AGND	59		9	AGND3
n/c	58		8	VCH3
AGND	57		7	AGND2
n/c	56		6	VCH2
	 55	•••		
AGND		••	5	AGND1
n/c	54	••	4	VCH1
AGND	53	••	3	AGND0
n/c	52	••	2	VCH0
AGND	51	L ••	1	AGND


#### PCI-DAC6703 connector pin out

Signal name	Pin		Pin	Signal name
GND	100	••	50	GND
n/c	99	••	49	n/c
n/c	98	••	48	DIO7
n/c	97		47	DIO6
GND	96		46	DIO5
n/c	95		45	DIO4
n/c	94		44	n/c
n/c	93		43	DIO3
DIO7	92		42	DIO2
DIO	91		41	DIO2
DIO5	90	•••	40	DIO
DIO3	89	•••	39	PC 5V
DIO4 DIO3	88	••	38	n/c
		••		
DIO2	87	••	37	n/c
DIO1	86	••	36	n/c
DIOO	85	••	35	n/c
AGND	84	••	34	AGND
n/c	83	• •	33	n/c
AGND	82	••	32	AGND
n/c	81	• •	31	n/c
AGND	80	• •	30	AGND
n/c	79	• •	29	n/c
AGND	78	••	28	AGND
n/c	77	• •	27	n/c
AGND	76	• •	26	AGND
n/c	75	• •	25	n/c
AGND	74	• •	24	AGND
n/c	73	• •	23	n/c
AGND	72	• •	22	AGND
n/c	71	• •	21	n/c
AGND	70	••	20	AGND
n/c	69	••	19	n/c
AGND	68	••	18	AGND
AGND	67	••	17	AGND7
n/c	66	••	16	VCH7
AGND	65	••	15	AGND6
n/c	64		14	VCH6
AGND	63	••	13	AGND5
n/c	62		12	VCH5
AGND	61		11	AGND4
n/c	60		10	VCH4
AGND	59		9	AGND3
n/c	58		8	VCH3
	57		0 7	
AGND		••		AGND2
	<u>56</u> 55	••	6	
AGND		••	5	AGND1
	54	••	4	VCH1
AGND	53	••	3	AGND0
	52	••	2	
AGND	51		1	AGND

#### PCI-DAC6702 connector pin out

#### Cabling





#### Field wiring and signal termination accessories

You can use the following BNC and screw terminal boards to terminate field signals and route them into the PCI-DAC6702 and PCI-DAC6703 boards using the C100HD50-x cable:

- BNC-16SE: Brings analog signals to standard BNC connectors. Designed for boards operating in singleended mode.
- BNC-16DI: Brings analog signals to standard BNC connectors. Designed for boards operating in differential mode.
- CIO-MINI50: 50-pin screw terminal board. Two boards are required.
- CIO-TERM100: 100-pin screw terminal board (daisy-chained 50-pin IDC connectors).
- SCB-50: 50-conductor, shielded signal connection/screw terminal box provides two independent 50-pin connections.

You can use the following screw terminal box and BNC connector box to terminate field signals and route them into the PCI-DAC6702 and PCI-DAC6703 board using the C100MMS-x cable:

- SCB-100: 100-conductor, shielded signal connection/screw terminal box provides two independent 50-pin connections.
- BNC-16DI-FE Brings analog signals to standard BNC connectors. Designed to be compatible with the 100-pin shielded C100MMS-x cable.

Details on these products are available on our website.

# Calibrating the PCI-DAC6702 and PCI-DAC6703

You should calibrate the board using the InstaCal utility software after the board has fully warmed up. The recommended warm-up time is 15 minutes. For best results, calibrate the board immediately before use. The high-resolution analog components on the board are temperature-sensitive, so calibrating the board before use ensures that your board is operating with the optimum calibration values. All calibration values are saved in nvRAM.

# **Calibration theory**

InstaCal calibrates the board's analog outputs for offset and gain (see Figure 4). A trim DAC is used to adjust the gain of the DAC. A separate DAC is used to adjust offset on the final output amplifier.




Figure 4. Analog output calibration

#### Calibration schedule

You should calibrate your PCI-DAC6702 and PCI-DAC6703 board once per year using the InstaCal calibration procedures.

# **Specifications**

#### Typical for 25 °C unless otherwise specified. Specifications in *italic text* are guaranteed by design

# Analog output

D/A converter type	Enhanced R-2R		
Resolution	16-bits, 1 in 65536		
Number of channels	PCI-DAC6703: 16 voltage		
	PCI-DAC6702: 8 voltage		
DNL	$\pm 1 LSB max$		
Monotonicity	16-bits, guaranteed after calibration		
Update rate, max	PCI-DAC6703: 1111 S/s per channel, 3.5 kS/s for all channels		
	PCI-DAC6702: 1111 S/s per channel, 3.5 kS/s for all channels		
Update modes	Software selectable per channel for update immediate (default), or update from NVRAM on command		
Output short-circuit duration	Indefinite @ 25 mA		
Power-on state	Independent, user-defined power-on states.		

Table 1. Analog output specifications

#### Table 2. Voltage output specifications

Range	±10.1 V
Output coupling	DC
Output impedance	0.1 Ω max.
Current drive	$\pm 10 \text{ mA max}$
Load capacitance	10,000 pF
Slew rate	0.5 V/µs typ.
Settling time (full scale step)	7.2 ms max to $\pm 0.5$ LSB
Noise	$100 \ \mu V_{rms}$ , DC to 1 MHz BW
Offset temperature coefficient	$\pm 5 \ \mu V/^{o}C$
Gain temperature coefficient	$\pm 1 ppm/°C$
Protection	Short circuit to ground
Data transfer	Programmed I/O

Table 3. Absolute accuracy components - all values are (±)

Range <sup>1</sup>	% of Reading	Offset	Temp Drift <sup>2</sup> (%/°C)	Absolute Accuracy at FS
$\pm 10 \ V$	0.0019	$\pm 710~\mu V$	0.0001	$\pm 1 \text{ mV}$

**Note 1:** Temp drift applies only if the ambient temperature changes by more than  $\pm 10^{\circ}$ C since the last calibration.

**Note 2:** Each PCI-DAC670x board is tested at the factory to assure that the overall error does not exceed the values specified in Table 3.

#### Table 4. Relative accuracy

Range	Relative Accuracy
±10 V	±1.0 LSB, max

Relative accuracy is defined as the measured deviation from a straight line drawn between measured endpoints of the transfer function.

# Analog output calibration

Recommended warm-up time	15 minutes
Calibration	Auto-calibration, calibration factors for each range stored on board in non-volatile RAM.
Onboard calibration reference	DC Level: 10.000 V±1 mV. Actual measured values stored in EEPROM.
	Tempco: 0.6 ppm/°C max
	Long-term stability: ±6 ppm/sqrt(1000 hrs)
Calibration interval	1 year

Table 5. Analog I/O calibration

# Digital input / output

#### Table 6. Digital I/O

Digital type	Discrete, 5 V/TTL compatible
Number of I/O	8
Configuration	8 bits, independently programmable for input or output. Position available for pull-up/pull-down resistor network (not populated).
Input high voltage	2.0 V min, 7.0 V absolute max
Input low voltage	0.8 V max, -0.5 V absolute min
Output high voltage $(IOH = -32 \text{ mA})$	3.80 V min, 4.20 V typ
Output low voltage (IOL = 32 mA)	0.55 V max, 0.22 V typ
Data transfer	Programmed I/O
Power-up / reset state	Input mode (high impedance)

## Power consumption

#### Table 7. Power consumption specifications

+5 V	PCI-DAC6703: 1.1 A max
	PCI-DAC6702: 1.0 A max
+5 V available at I/O connector	0.75A max, protected with a resettable fuse

## Environmental

Table 8. Environmental specifications

Operating temperature range	0 to 55 °C
Storage temperature range	-20 to 70 °C
Humidity	0 to 90% non-condensing

## Mechanical

Table 9. Mechanical specifications

Card dimensions	PCI half card: 174.4 mm (L) x 106.9 mm (W) x18.4 mm (H)
Form factor Universal PCI keying. Compatible with either 3.3 V or 5 V PCI sign	
	environments.

# Main connector and pin out

Connector type	Shielded SCSI 100 D-Type	
Compatible cables	e cables C100HD50-x, unshielded ribbon cable.	
	x = 3  or  6  feet	
	C100MMS-x, shielded round cable.	
	x = 1, 2,  or  3  meters	
Compatible accessory products	BNC-16SE	
(with C100HD50-x cable)	BNC-16DI	
	CIO-MINI50	
	CIO-TERM100	
	SCB-50	
Compatible accessory products	SCB-100	
(with C100MMS-x cable)	BNC-16DI-FE	

Table 10. Main connector specifications

1         AGND         51         AGND           2         VCH0         52         n/c           3         AGND0         53         AGND           4         VCH1         54         n/c           5         AGND1         55         AGND           6         VCH2         56         n/c           7         AGND2         57         AGND           8         VCH3         58         n/c           9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           20         AGND8         70         AGND           21         VCH8         69         n/c	Pin	Signal Name	Pin	Signal Name
2         VCH0         52         n/c           3         AGND0         53         AGND           4         VCH1         54         n/c           5         AGND1         55         AGND           6         VCH2         56         n/c           7         AGND2         57         AGND           8         VCH3         58         n/c           9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND3         59         AGND           12         VCH5         62         n/c           13         AGND6         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND         68         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND9         72         AGND           21         VCH9         71         n/c				
3         AGND0         53         AGND           4         VCH1         54         n/c           5         AGND1         55         AGND           6         VCH2         56         n/c           7         AGND2         57         AGND           8         VCH3         58         n/c           9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c		VCH0		
4         VCH1         54         n/c           5         AGND1         55         AGND           6         VCH2         56         n/c           7         AGND2         57         AGND           8         VCH3         58         AGND           9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND6         68         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND1         74         AGND           23         VCH10         75         n/c				
5         AGND1         55         AGND           6         VCH2         56         n/c           7         AGND2         57         AGND           8         VCH3         58         n/c           9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH6         64         n/c           17         AGND7         67         AGND           18         AGND7         67         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND1         76         AGND </td <td></td> <td></td> <td></td> <td></td>				
6         VCH2         56         n/c           7         AGND2         57         AGND           8         VCH3         58         n/c           9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND11         76         AGND           25         VCH11         75         n/c </td <td></td> <td></td> <td></td> <td></td>				
7     AGND2     57     AGND       8     VCH3     58     n/c       9     AGND3     59     AGND       10     VCH4     60     n/c       11     AGND4     61     AGND       12     VCH5     62     n/c       13     AGND5     63     AGND       14     VCH6     64     n/c       15     AGND6     65     AGND       16     VCH7     66     n/c       17     AGND7     67     AGND       18     AGND     68     AGND       19     VCH8     69     n/c       20     AGND8     70     AGND       21     VCH9     71     n/c       22     AGND9     72     AGND       23     VCH10     73     n/c       24     AGND10     74     AGND       25     VCH11     75     n/c       26     AGND11     76     AGND       27     VCH12     77     n/c       28     AGND13     80     AGND       30     AGND13     80     AGND       31     VCH12     77     n/c       32     AGND13	6			
8         VCH3         58         n/c           9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND         68         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND13         80         AG		AGND2		AGND
9         AGND3         59         AGND           10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH8         69         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80 <t< td=""><td></td><td>VCH3</td><td></td><td></td></t<>		VCH3		
10         VCH4         60         n/c           11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND8         70         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         <				
11         AGND4         61         AGND           12         VCH5         62         n/c           13         AGND5         63         AGND           14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND13         79         n/c           28         AGND13         80         AGND           29         VCH12         77         n/c           28         AGND13         80         AGND           30         AGND13         80		VCH4		n/c
12     VCH5     62     n/c       13     AGND5     63     AGND       14     VCH6     64     n/c       15     AGND6     65     AGND       16     VCH7     66     n/c       17     AGND7     67     AGND       18     AGND     68     AGND       19     VCH8     69     n/c       20     AGND8     70     AGND       21     VCH9     71     n/c       22     AGND9     72     AGND       23     VCH10     73     n/c       24     AGND10     74     AGND       25     VCH11     75     n/c       26     AGND11     76     AGND       27     VCH12     77     n/c       28     AGND13     80     AGND       30     AGND13     80     AGND       31     VCH12     77     n/c       29     VCH13     79     n/c       30     AGND14     82     AGND       31     VCH15     83     n/c       33     VCH16     84     NC       34     AGND15     84     AGND       35     n/c		AGND4		
13       AGND5       63       AGND         14       VCH6       64       n/c         15       AGND6       65       AGND         16       VCH7       66       n/c         17       AGND7       67       AGND         18       AGND       68       AGND         19       VCH8       69       n/c         20       AGND8       70       AGND         21       VCH9       71       n/c         22       AGND9       72       AGND         23       VCH10       73       n/c         24       AGND1       74       AGND         25       VCH11       75       n/c         26       AGND11       76       AGND         27       VCH12       77       n/c         28       AGND13       80       AGND         30       AGND13       80       AGND         31       VCH12       77       n/c         33       VCH14       81       n/c         34       AGND15       84       AGND         35       n/c       85       DIO1         36				
14         VCH6         64         n/c           15         AGND6         65         AGND           16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND15         83         n/c           33         VCH15         83         n/c           34         AGND15         84	13		63	AGND
15       AGND6       65       AGND         16       VCH7       66       n/c         17       AGND7       67       AGND         18       AGND       68       AGND         19       VCH8       69       n/c         20       AGND8       70       AGND         21       VCH9       71       n/c         22       AGND9       72       AGND         23       VCH10       73       n/c         24       AGND10       74       AGND         25       VCH11       75       n/c         26       AGND11       76       AGND         27       VCH12       77       n/c         28       AGND12       78       AGND         29       VCH13       79       n/c         30       AGND13       80       AGND         31       VCH14       81       n/c         32       AGND15       84       AGND         33       VCH15       83       n/c         34       AGND15       84       AGND         35       n/c       86       DIO1         36	14		64	
16         VCH7         66         n/c           17         AGND7         67         AGND           18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND12         77         n/c           28         AGND12         77         n/c           28         AGND13         80         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND15         84         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         86				
17       AGND7       67       AGND         18       AGND       68       AGND         19       VCH8       69       n/c         20       AGND8       70       AGND         21       VCH9       71       n/c         22       AGND9       72       AGND         23       VCH10       73       n/c         24       AGND10       74       AGND         25       VCH11       75       n/c         26       AGND10       74       AGND         27       VCH12       77       n/c         28       AGND12       78       AGND         29       VCH13       79       n/c         30       AGND13       80       AGND         31       VCH14       81       n/c         32       AGND14       82       AGND         33       VCH15       83       n/c         34       AGND15       84       AGND         35       n/c       85       DIO0         36       n/c       86       DIO1         37       n/c       89       DIO4         36				
18         AGND         68         AGND           19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND13         80         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         87         DIO2           38         n/c         88				
19         VCH8         69         n/c           20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         87         DIO1           37         n/c         88         DIO1           36         n/c         88         DIO1           37         n/c         89 <td< td=""><td></td><td></td><td></td><td></td></td<>				
20         AGND8         70         AGND           21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND15         83         n/c           33         VCH15         83         n/c           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         88         DIO2           38         n/c         89				
21         VCH9         71         n/c           22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         89         DIO4           40         DIO         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92 <t< td=""><td></td><td></td><td></td><td>AGND</td></t<>				AGND
22         AGND9         72         AGND           23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           33         VCH15         84         AGND           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         89         DIO4           40         DIO0         90         DIO5           41         DIO2         92				
23         VCH10         73         n/c           24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92		AGND9		
24         AGND10         74         AGND           25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND13         80         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93				
25         VCH11         75         n/c           26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94 <td< td=""><td></td><td></td><td></td><td></td></td<>				
26         AGND11         76         AGND           27         VCH12         77         n/c           28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95				
27       VCH12       77       n/c         28       AGND12       78       AGND         29       VCH13       79       n/c         30       AGND13       80       AGND         31       VCH14       81       n/c         32       AGND14       82       AGND         33       VCH15       83       n/c         34       AGND15       84       AGND         35       n/c       85       DIO0         36       n/c       86       DIO1         37       n/c       87       DIO2         38       n/c       88       DIO3         39       PC 5V       89       DIO4         40       DIO0       90       DIO5         41       DIO2       92       DIO7         43       DIO3       93       n/c         44       n/c       94       n/c         45       DIO4       95       n/c				
28         AGND12         78         AGND           29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
29         VCH13         79         n/c           30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
30         AGND13         80         AGND           31         VCH14         81         n/c           32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
31       VCH14       81       n/c         32       AGND14       82       AGND         33       VCH15       83       n/c         34       AGND15       84       AGND         35       n/c       85       DIO0         36       n/c       86       DIO1         37       n/c       87       DIO2         38       n/c       88       DIO3         39       PC 5V       89       DIO4         40       DIO0       90       DIO5         41       DIO1       91       DIO6         42       DIO2       92       DIO7         43       DIO3       93       n/c         44       n/c       94       n/c         45       DIO4       95       n/c				
32         AGND14         82         AGND           33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
33         VCH15         83         n/c           34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c		AGND14		AGND
34         AGND15         84         AGND           35         n/c         85         DIO0           36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c		VCH15		
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$				
36         n/c         86         DIO1           37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
37         n/c         87         DIO2           38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
38         n/c         88         DIO3           39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
39         PC 5V         89         DIO4           40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
40         DIO0         90         DIO5           41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
41         DIO1         91         DIO6           42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
42         DIO2         92         DIO7           43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
43         DIO3         93         n/c           44         n/c         94         n/c           45         DIO4         95         n/c				
44         n/c         94         n/c           45         DIO4         95         n/c				
45 DIO4 95 n/c				
	45	DIO4	95	n/c
46   DIU5   96   GND	46	DIO5	96	GND
47 DIO6 97 n/c	47	DIO6	97	
48 DIO7 98 n/c	48	DIO7		
49 n/c 99 n/c	49	n/c	99	
	50	GND		GND

#### Table 11. PCI-DAC6703 pin out

Note: DIO[7:0] signals are provided in two locations in order to provide flexibility for applications which use the C100HD50-x ribbon cable.

Pin	Signal Name	Pin	Signal Name
1	AGND	51	AGND
2	VCH0	52	n/c
3	AGND0	53	AGND
4	VCH1	54	n/c
5	AGND1	55	AGND
6	VCH2	56	n/c
7	AGND2	57	AGND
8	VCH3	58	n/c
9	AGND3	59	AGND
10	VCH4	60	n/c
11	AGND4	61	AGND
12	VCH5	62	n/c
13	AGND5	63	AGND
14	VCH6	64	n/c
15	AGND6	65	AGND
16	VCH7	66	n/c
17	AGND7	67	AGND
18	AGND	68	AGND
19	n/c	69	n/c
20	AGND	70	AGND
21	n/c	71	n/c
22	AGND	72	AGND
23	n/c	73	n/c
24	AGND	74	AGND
25	n/c	75	n/c
26	AGND	76	AGND
27	n/c	77	n/c
28	AGND	78	AGND
29	n/c	79	n/c
30	AGND	80	AGND
31	n/c	81	n/c
32	AGND	82	AGND
33	n/c	83	n/c
34	AGND	84	AGND
35	n/c	85	DIO0
36	n/c	86	DIO1
37	n/c	87	DIO2
38	n/c	88	DIO3
39	PC 5V	89	DIO4
40	DIO0	90	DIO5
41	DIO1	91	DIO6
42	DIO2	92	DIO7
43	DIO3	93	n/c
44	n/c	94	n/c
45	DIO4	95	n/c
46	DIO5	96	GND
47	DIO6	97	n/c
48	DIO7	98	n/c
49	n/c	99	n/c
50	GND		GND

**Note 3:** DIO[7:0] signals are provided in two locations in order to provide flexibility for applications which use the C100HD50-x ribbon cable.

# CE Declaration of Conformity

Manufacturer:	Manufacturer: Measurement Computing Corporation	
Address:	10 Commerce Way	
	Suite 1008	
	Norton, MA 02766	
	USA	
Category:	Electrical equipment for measurement, control and laboratory use.	

Measurement Computing Corporation declares under sole responsibility that the product

#### PCI-DAC6702 and PCI-DAC6703

to which this declaration relates is in conformity with the relevant provisions of the following standards or other documents:

EC EMC Directive 2004/108/EC: Electromagnetic Compatibility, EN 61326-1:2006 (IEC 61326-1:2005)

Emissions: Group 1, Class B

• EN 55011(1990)/CISPR 11: Radiated and Conducted emissions.

Immunity: EN61326-1:2006, (IEC 61326-1:2005)

- EN61000-4-2 (2001): Electrostatic Discharge immunity.
- EN61000-4-3 (2002): Radiated Electromagnetic Field immunity.
- EN61000-4-4 (2004): Electric Fast Transient Burst immunity.
- EN61000-4-5 (2001): Surge immunity.
- EN61000-4-6 (2003): Radio Frequency Common Mode immunity.
- EN61000-4-11 (2004): Voltage Dip and Interrupt immunity.

Declaration of Conformity based on tests conducted by Chomerics Test Services, Woburn, MA 01801, USA in May, 2004. Test records are outlined in Chomerics Test Report #EMI3887.04. Further testing was conducted by Chomerics Test Services, Woburn, MA. 01801, USA in December, 2008. Test records are outlined in Chomerics Test report #EMI5241.08.

We hereby declare that the equipment specified conforms to the above Directives and Standards.

Cel Haypage

Carl Haapaoja, Director of Quality Assurance

Measurement Computing Corporation 10 Commerce Way Norton, Massachusetts 02766 (508) 946-5100 Fax: (508) 946-9500 E-mail: <u>info@mccdaq.com</u> www.mccdaq.com NI Hungary Kft H-4031 Debrecen, Hátar út 1/A, Hungary Phone: +36 (52) 515400 Fax: +36 (52) 515414 http://hungary.ni.com/debrecen